



## **A. XADDR1**

- The resistor should be connected to the XADDR1 pin in order to load the selected image to the memory at power up.

## **B. .xsf Configuration File**

- Click the box to select a image to be added or deleted. After selection, click “Add file” or “Delete selected file” button.

## **C. i2c address**

- This is the i2c address of the image in the xsf file for identifying the loaded image.

## **D. Add file**

- Add configuration data to the selected image location

## **E. Create xcf file**

- Click to create the multi image configuration file

## **F. Load xcf file**

- Click to load a previously saved xcf file

## **G. Delete selected file**

- Click to delete the selected configuration file

## **H. Delete all xsf file**

- Click to delete all configuration files in the above xsf file table