

PG160-B02

8GB GDDR6, 256b, X16

Tall DVI-D + USBC/DP + DP + HDMI/DP + DP

TABLE OF CONTENTS

Page Description

1	Table of Contents
2	Block Diagram
3	PCI Express
4	PCIE RC TERM
5	MEMORY: GPU FB_AB
6	MEMORY: FBA[31:0]
7	MEMORY: FBA[63:32]
8	MEMORY: FBB[31:0]
9	MEMORY: FBB[63:32]
10	MEMORY: GPU FB_CD
11	MEMORY: FBC[31:0]
12	MEMORY: FBC[63:32]
13	MEMORY: FBD[31:0]
14	MEMORY: FBD[63:32]
15	GPU PWR & GND
16	GPU Decoupling
17	GPU Decoupling2
18	IO: IFPAB DVI-D-DL
19	IO: IFPE DP
20	IO: IFPF USBC
21	IO: IFPC HDMI/DP
22	IO: IFPD DP
23	IO: NVHS Interface and Frame Lock
24	MISC1: Thermal, JTAG, GPIO,STEREO
25	MISC2: ROM, XTAL,STRAPS


Page Description

26	PS: 1V8_PLL, 1V8_AON
27	PS: 5V
28	PS: PEXVDD
29	PS: FBVDDQ
30	PS: FBVDDQ PH2
31	PS: NVVDD Controller
32	PS: NVVDD Controller OVR3i
33	PS: NVVDD Phase 1,2
34	PS: NVVDD Phase 3,4
35	PS: NVVDD Phase 5,6
36	PS: Input Power Balancing Switcher
37	PS: Input, Filtering, and Monitoring
38	PS: STEERING, UPB & HOT-UNPLUG
39	PS: Type-C BuckBoost
40	PD PPC
41	PS: 12V & 3V3_A SWITCHER
42	SEQ: 5V, 1V8, NV3V3 ENABLE
43	SEQ: NV, PEX, FB ENABLE
44	SEQ: VOLTAGE MONITOR
45	SEQ: DISCHARGE
46	SEQ: MISC
47	LOGO LED
48	LED DRIVER & BOOST
49	DUAL FAN
50	PS: Pre-filter

Page Description


51	MECH
52	PTC
53	Power Delivery
54	LED_CONTROLLER_IT8295


СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!




СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!

POWER SUPPLY















СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!





MICRO-STAR INT'L CO.,LTD			
MS-V375			
Size Custom	Document Description PCI Termination		Rev 4.0
Date: Friday, November 09, 2018		Sheet 4 of 54	























СКАЧАНО С WWW.SIBBAND-ПРОСОЕДИНЕНИЯ.СН






FBVDDQ




СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!


Under GPU





Near GPU




1V8_AON



NVDD



СКАЧАНО С WWW.SV.BAND.РРИСОЕДИНЯЙСЯ




If an IFP link is unused, in general it should be left unconnected. This includes Main and Aux links. IFPxy_RSET and IFPxy_PLLVDD (xy=AB,CD,EF) can be left unconnected if neither of IFPx /IFPy is in use. For example, If neither link of the IFPA/IFPB macro is to be used, then IFPAB_PLLVDD and IFPAB_RSET should be left disconnected, and all signals and references associated with Link A and Link B should also be left unconnected.

IFP_IOVDD rail can be unconnected if no IFP link is used.If any IFP is used, all IFP_IOVDD balls must be connected to power rail.

Unused IFPB_I2C* leaving Pull high resistor to 1.8V ◦


СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!

1 used V328 3 0 DP symbol stuff ed DP
2 delete USB C





СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!





delete Frame Lock ◦





STRAP2	STRAP1	STRAP0	RAMCFG[4:0]
L	L	L	00000
L	L	H	00001
L	H	L	00010
L	H	H	00011
H	H	L	00110
H	H	H	00111
L	L	M	01000

RAMCFG[4:0]	DENSITY	WIDTH	VENDOR	DIE
00000	8Gb	256-bit	Samsung	C
00001	8Gb	256-bit	Micron	A
00010	8Gb	256-bit	Hynix	M
00011	8Gb	256-bit	Samsung	C
00100	8Gb	256-bit	Micron	A
00101	8Gb	256-bit	Hynix	M
00110	16Gb	256-bit	Samsung	M
00111				

ROM_SO	ROM_SI	ROM_SCLK	DUMMY[2:0].FS_OVERT	1.ENABLE 0.DISABLE	DEFAULT
L	L	L	XXX1	FS_OVERT ENABLE	
L	L	M	XXX0	FS_OVERT DISABLE	






STRAP5	STRAP4	STRAP3	SMB_ALT_ADDR	DEVID_SEL	PCIE_CFG	VGA_DEVICE
M	H	H	1		1	1
M	H	L	1		1	0
M	L	H	1		0	1
M	L	L	1		0	0
L	H	M	1		1	1
L	M	H	1		1	0
L	M	L	1		0	1
L	L	M	1		0	0
H	H	H	0		1	1
H	H	L	0		1	0
H	L	H	0		0	1
H	L	L	0		0	0
L	H	H	0		1	1
L	H	L	0		1	0
L	L	H	0		0	1 DEFAULT
L	L	L	0		0	0

H=High :Tied to 1.8V
M=Middle:Tied to 0.9V
L=Low :Tied to 0V


1:SMB_ALT_ADDR ENABLE
0:SMB_ALT_ADDR DISABLE
1:DEVID_SEL REBRAND
0:DEVID_SEL ORIGINAL

1:PCIE_CFG LOW POWER
0:PCIE_CFG HIGH POWER
1:VGA_DEVICE ENABLE
0:VGA_DEVICE DISABLE

СКАЧАНО С WWW.SW.BAND.PRSОЕДИНЯЙСЯ



XTALOUTBUFF		
1.8V	0.9V	0V
80% PWM	33% PWM	DISABLED (100%)




```

1 L503 PN L04-0107410-L65 / footprint : CHK_S2_3X6_61
2 delete colayout P WM ouput choke
3 delete 1V8_MA N and merged to 1V8_AON

```

СКАЧАНО С WWW.SV.BAND - ПРИСОЕДИНЯЙСЯ!


- ```
1 L510 PNL04-0507010-L65 / footprint : CHK_S2_5_4X5_23
2 delete colayout PWM output choke
3 unused RTD8 delete Buck-Boost regulator
```









СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!











КАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!



delete all unused

СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!







removed U511 for fi xed NVVDD 12Vi nput:  
1 \merged 3V3\_AON to 3V3\_F  
2 unused and dēēē 3V3\_AUX  
3 unused and dēēē 3V3\_AUX\_CON  
4 \NVVDD\_DYN\_V N merged to 12V\_PEX6\_8\_F1







Delete GPOL\_INPUT\_DYN\_BAL1  
Delete INPUT\_PEX6\_DT1\_STEER

СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!

```

1 changed EXT 12V 8pin PN and footprint.
2 add EXT 12V 8pin Fuse.
3 delete unused parts.
4 RSENSE 3 change to sense NVVDD PEX 12V.
5 RSENSE 4 change to sense NVVDD EXT 12V.
6 change RSENSE parts and footprint.

```



Sense resistors should be located as close as possible to the OVR-M input pins. Otherwise sensor output signals may exhibit larger measurement errors due to additional trace inductance and noise coupling in the signal from nearby noise-generating sections of the board.




Figure 5.10 Connection for 2-Pin Sense Resistor (2512 Package)

If customer prefers using a 2-pin sense resistor instead, we recommend implementing a 4-pin footprint with two large PADs for the high current path and two small PADs for sensing line, to emulate the functionality of a 4-pin resistor.

**Note:** Two-pin sense resistor can be used, but the sensing signal **MUST** connect to resistor pad directly. Connect the sensing signal to nearby power plane may cause large measurement error.



|                                 |                                                                      |       |            |
|---------------------------------|----------------------------------------------------------------------|-------|------------|
| <b>MICRO-STAR INT'L CO.,LTD</b> |                                                                      |       |            |
| <b>MS-V375</b>                  |                                                                      |       |            |
| Size<br>Custom                  | Document Description<br><b>PS: Inputs, Filtering, and Monitoring</b> |       | Rev<br>4.0 |
| Date: Friday, November 09, 2018 |                                                                      | Sheet | 37 of 54   |



delete regulator for USBC\_VBUS °

Unused USB\_I2C\* leaving Pull high resistor to 1.8V °

СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!

delete PPC °

Unused USB\_I2C\* leaving Pull high resistor to 1.8V °

Unused IFPB\_I2C\* leaving Pull high resistor to 1.8V °

delete GPIO4\_IPPF\_HPD °

delete PEX\_RST\_BUF\* °

delete GPIO1\_GCS\_FB\_EN °

СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!


unused and delete all °

delete \_GP001\_GCE\_FB\_EN+  
delete \_GP002\_DUE\_IN\_SW1

delete \_offpage\_P5\_BTD\_SWITCH

СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!


unused\_and\_delete\_C404







СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!

## Route the trace to PCX Golden Finge




| OPTIONS                     | PEX3V3_SENSE    | PEX12V_SENSE    | OTHER_12V_SENSE |
|-----------------------------|-----------------|-----------------|-----------------|
| Use Pre-Filter              | Pre-Filter      | Pre-Filter      | Pre-Filter      |
| Use INA3221                 | Voltage_Monitor | INA3221         | INA3221         |
| NO INA3221<br>NO Pre-Filter | Voltage_Monitor | Voltage_Monitor | N/A             |





СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!



СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!


delete all unused

СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!

delete all unused

СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!


copied V373-2.0 housing PN and footprint °




СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!



Brackets:





MOUNTING HOLES FOR HS:





СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!

Mechanical Holes Symbol




Bracket Screw




improved FBVDDQ PSU parts don't require a PTC

СКАЧАНО С WWW.SW.BAND - ПРИСОЕДИНЯЙСЯ!



Power on Sequence



СКАЧАНО С WWW.SW.BAND-ПРИСОЕДИНЯЙСЯ!

